

optional



SETUP12

Insert the "T" shaped screws and put on the nut.
Push the "T" into the profile making sure the
"T" screw is in the locking position.