


Step 1. Attach front to sides using 4 short knobs.

Step 2. Attach back to sides using 4 short knobs.

Step 3. Attach top to sides using 2 short knobs.

Step 4. Insert shelves.



airbornevisuals

1315 Walnut St., Ste 1616, Philadelphia, PA 19107
www.airbornevisuals.com 800.821.2241