

iPad Stand Pro Hybrid Frame

1. Align tablet upright over base. Feed tablet cord through center hole and screw into place using two (2) Allen head screws. When inserting screws, tighten BOTH by hand first. Then, fully tighten using an Allen key. Align frame upright over base and screw into place using Allen screw provided.
2. Attach the strap to the tablet upright, then attach the opposite end to the base, using the screws provided.
3. Attach the Tablet casing to the upright as shown below using the bolt and washers provided. Use the magnetic tightening tool provided to tighten the bolt.
4. Remove acrylic cover using small tamper-proof key provided. Place tablet inside and reassemble unit. If ball joint loosens on back, use the large tamper-proof key to retighten it securely.
5. Align knob rest glides/frame brackets with the upright channel. Slide knob rest glides into upright channel, sandwich bracket in between, and tighten to secure frame bracket to the upright.
6. Repeat for opposite frame (**for IPF2 only**).
7. Press cap into upright to finish unit.

NOTE: Frame sizes and quantity vary per model.



Applicable Products:

- IPF1 (Single Frame)
- IPF2 (Double Frame)

