

Aero

This indoor/outdoor modular backwall is one of the most versatile on the market. With adjustable height and angles, there are multiple configurations possible. It is available in a complete kit or a la carte to create more combinations.



Features and Benefits

- Stable bases and articulated design allows for multiple configurations
- Can be used for trade show displays or outdoor marketing
- Can be purchased in a kit or a la carte
- Easy to assemble and transport

Additional Information

Shipping Information

Upright Box: 47" x 4.5" x 4", 7 lbs
 1200mm Cassette: 53" x 5" x 4", 10 lbs
 Base Box: 18" x 18" x 3", 9lbs

Graphic Information:

Graphic Substrate: Smooth Vinyl, Cotton, or Anti-Curl Vinyl

Included in basic kit: four bases, 4 uprights, 3 1200 mm banners In full kit: add 2 lights, OCH hard case

Pole Diameter: 3.25" at widest point

Graphic Dimensions:


Center Graphic:

Full: 47"w x 79.125"h
 Half: 47"w x 59.375"h
 Half (pulling down from fully extended poles): 47"w x 37"h
 Quarter: 47"w x 41.375"h

Side Graphics:

Full: 47"w x 79.125"h
 Half: 47"w x 59.375"h
 Half (pulling down from fully extended poles): 47"w x 37"h
 Quarter: 47"w x 41.375"h

*Add 6" bleed at the top and 3.75" bleed at the bottom



1



2



Unscrew wing-nut located at the bottom of each pole

7



Pull graphic down from cassette by rail edge

8



Fasten graphic rail edge to hanger at bottom of pole

3




Attach poles to disk base with wing-nut

4



Insert graphic cassette/rail hangers in the slots at top of poles where graphic cassettes will be

9



simply turn the graphic tensioner clockwise to create more tension



5



Adjust poles to desired height by using the release buttons on sides of poles

6



Hang graphic cassettes by inserting opening at end of cassette over rail hangers at top of pole

